

**Request for Information on CRV project**  
**Questions/answers 5**

**08 Oct. 14**

**Questions from vendor**

1. What's the difference between "Provide minimum Port Speed" and "Provide minimum Ethernet Port Speed"?
2. Which of this is referring to the IPVPN bandwidth?

**Answers**

1. There is no column 'Provide minimum Ethernet Port Speed'. The Column S states 'Provide maximum Ethernet Port Speed' which refers to the maximum speed available on the Ethernet Port. The column R 'Provide minimum Port Speed' is the port bandwidth available from the service provider.
2. In this case, the column R 'Provide minimum port Speed' refers to IPVPN bandwidth.