

ICAO Frequency Finder Easy Reference for Exercise

AFI Introductory Virtual Workshop

Presentation 3

Presented by

Mie Utsunomiya – ICAO HQs

Fabiola Chouha - ICAO HQs

11 May 2022



Start page and SSR Home page




① Click "SSR"


Home page

Home



2 Click "AFI"






③ "Integrity Check" will start" – See Next slide




Main functions on the window SSR Table

Regular and new functions – NewMod Facility and Test Mode Facility






Main functions on the window SSR TableRegular and new functions – New Facility






Main functions on the window SSR Table

Regular and new functions - New facility






Main functions on the window SSR Table Regular and new functions – Mod / Add Facility





Main functions on the window SSR Table Regular and new functions – Mod / Add Facility






Main functions on the window SSR Table (cont'd) Regular and new functions - Mapping






Main functions on the window SSR Table (cont'd) Regular and new functions - Query






Main functions on the window SSR Table (cont'd) Regular and new functions – Export submissions





Main functions on the window SSR Table (cont'd)


Regular and new functions – Export facilities to file





Main functions on the window SSR Table (cont'd)

Regular and new functions – Export facilities to file



Questions

